





Quick Start Guide- Digital Recordable Car Jukebox PD-300-01


Part List

1. Navigator & Remote Control


The keys on the navigator panel include:


Power on/off key

Navigator key     - left, right, up, down for browsing & select


Play/Pause key 

Stop key  - to stop playing or recording

Record key 

Advance key  - to go to play mode & song search menu

Fast Backward  & Fast Forward  keys

Edit key  - to edit the file name or delete a song/ folder

Mark key  - to add songs to the templist.

The additional keys on the remote control include:

Save key - for saving temp list to playlist

Alphanumeric key- for song editing & fast accessing a song

F1-F3- no function

2. Trunk Unit (TU)

The trunk unit can be mounted inside the trunk of the car. It requires the following connections:

- Connect to the Navigator Unit.
- Connect line-out and line-in to the head unit via RCA cables.
- Connect to the +12V car power supply.

3. Removable Hard Drive Unit (HDU)

The HDU can be removed from the TU and connect to the PC for downloading songs and uploading voice recordings. It requires the following connections:

- Connect to the provided +12V DC power supply
- Connect to the PC USB port with a USB cable (not included)
- Connect line out to the amplifier and line-in to other audio source

Setup in Car Environment

1. Connect the Navigator to the Trunk Unit (TU) using the serial cable.
2. Slide the Hard Disk Unit (HDU) into the TU.
3. Connect the line-out on the TU to the car's head unit line-in, amplifier line-in or an FM modulator line-in if your head unit does not have line-in*.
4. Connect the line-in on the TU to the car's head unit line-out, or any other audio source.
5. Connect car battery power to the TU's purple power wire labeled with "Battery (B+)".
6. Connect car switched power to TU's red power wire labeled with "Power B (+)"
7. Connect the car power ground to TU's black wires labeled with "Ground"
8. Power on the Navigator

9. The red LED on navigator and HDU are on
10. When the right green LED is on. That represents the system is ready.

Remarks: Resume last status function:

When power on the unit, the system will resume the last status in car environment. The last status will be cleared after HDU is used with PDJockey.

* Please refer to the attached installation guide to set up the FM modulator.













PC Software Installation (PDJockey Software)

1. Insert the installation CD. The installation will run automatically.
2. Select "Digital Recordable Car Jukebox" and click on OK.
3. Follow the steps to install the software.
4. During installation, the USB drive will be automatically installed.
5. Re-start your PC when installation is complete.

Transferring Songs to the Hard drive (HDU)


1. Turn off the power on the Navigator.
2. Pull the HDU out from the TU if it's in the TU.
3. Connect the provided 12V power supply to the HDU
4. Connect the HDU with PC via a USB cable
5. Turn on the power switch on the HDU and wait until the USB Green LED is lit.
6. Start the PDJockey on the PC. You can find "PDJockey for Digital Recordable Car Jukebox" in the programs in your start menu after successful installation.
7. Drag your files from left window and drop them to the right. You can also edit the file name in PDJockey.
8. After you finished, close the PDJockey on the PC and turn off the power switch.

Playing a Song

1. If it is not in the Main Browsing screen, use the  key until you go to the Main Browsing screen.
2. Use  and  keys to select "By Album" and then use the  key to go inside to view all available albums. (You can press  key to start playing all songs in the entire hard disk immediately.)
3. Use  and  keys to select your desired album and press  key to go inside the view all songs in your selected album. (You can press  key to start playing all songs in your selected album immediately.)
4. Use  and  keys to select your desired song, press  key to start playing from your selected song.

#The interface is the same for browsing by Artist, Playlist or Templist.

Notes on playback:

1. Press  &  key go to the previous or next song or

hold & to scan within the track during playback.)

2. During playback, pressing and keys will go to the first song of previous or next album.
3. The play mode function includes: repeat one, repeat all, random one, random all and intro. For selecting play mode, please refer to the advance mode section.

Recording from Line-in/ Mic-in

1. Press key to enter the Record mode.
2. Use to select mic-in and use to select line-in. The recording will start.
3. Press key to stop the recording.
4. The recorded file will be saved in Line-In Collection directory in the album browsing mode.

Notes:

There is silence detect for line in signal input for song separation. The car unit will wait until there is line-in signal input or user can press to separate songs manually.

One-Touch Voice Recording and Instant Playback

1. Press and hold key for one second, the voice recording will start.
2. User can press key to stop the voice recording and then the system will prompt the user whether to playback the voice recording instantly.
3. Press key to play the recorded file instantly or press key to exit without instant playback.

Advance Function - Selecting Play Mode

1. Press key once to go to play mode
2. Use and keys to select the Play Mode: Normal, Intro, Random All, Random One, Repeat Disc, and Repeat one.
3. Press key to save and exit the Play Mode or after 4 seconds will automatically exit.

Advance Function - Selecting Search mode

1. Press the key twice to go to search mode
2. Use and keys to browse searching by Album, Artist or Song Name, and then press key to select.
3. Use the and keys to enter the keyword or use remote to enter keywords and press key to start searching
4. Use and keys to browse the result of all matched songs and press key to play.

Fast Numeric Browsing

The user can fast browse the Song/ Album/ Artist/ Playlist by inputting the index number using remote. For example, if user wants to search 100th song, the user can input '1', '0', and '0' and press 'Enter' to fast browsing your desired song.

Creating a Playlist

1. Select a desired song/Album/ Artist
2. Press the key (on Navigator / remote control) to add the song/ album/ artist to the temporary list.
3. You can keep adding max 200 songs to the Temp List.
4. User can view all the songs in the temp list (Browse Mode / Temp List)

5. Go to templist in main browsing screen, press
6. Press the key to save the Temp list to Playlist using navigator. Press save if using remote control.
7. You can find the playlist in the playlist directory.

Editing a song or a folder

1. Select the desired song or folder which you want to edit the name.
2. Press to enter the Edit mode
3. Use the and keys to select the Edit by Song name, Edit by Artist, Edit by Album, Press the key to enter the file which requires editing
4. You can now edit the name using and key to move to the cursor and use and keys to change the letters.
5. Press the key (use the navigator) to delete the selected character.

After you finished, press the key to save the change, or press to quit without saving the changes.

Deleting a song or a folder

1. Select the desired song or folder
 2. Press twice to enter the delete mode
 3. The LCD will display " Delete this dir." Or "Delete this song"
- Press the key to confirm the deletion, or press the to quit without delete.